



Installation Instructions

49MM Quarter Fairing Bracket Kit

Parts List:

- Adapter Brackets (2)
- Quick Release Mechanism (2)
- 5/16 x 24 Bolts (4)
- Aluminum Spacer
- Longer 3/8 Bolt
- Factory Headlight Riser Block (removed during installation)

Installation Steps:

- 1. Position the Adapter Brackets:**
 - The smaller tab on the adapter bracket should face the headlight.
 - The factory bracket that attaches to the fairing should sit inside the supplied adapter brackets.
- 2. Mount the Quick Release Mechanism:**
 - The lever of the quick release should be facing away from the headlight.
 - Use the 5/16 x 24 bolts (4 total) to bolt the quick release mechanism onto the adapter brackets.
- 3. Install the Aluminum Spacer:**
 - Place the aluminum spacer underneath the factory headlight riser block.
 - Secure it using the longer 3/8 bolt. This will raise the headlight approximately 1 inch from its original position.
- 4. Remove the Headlight and Factory Block:**
 - When removing the headlight from the lower tree, you'll also need to remove the pinch bolt holding the headlight to the factory riser block.
 - The factory riser block is offset drilled, so it needs to be rotated 180 degrees and reinstalled.
- 5. Position the Headlight:**
 - After rotating the factory block, reinstall it. This will position the headlight further forward and allow it to align with the foam gasket on the quarter fairing.
- 6. Check Alignment:**
 - Make sure the headlight is positioned properly to sit against the foam gasket of the fairing, ensuring a tight fit.
- 7. Review Pictures:**
 - Refer to the installation pictures on the website for visual guidance.

This should help you properly install the headlight with the new spacer and quick-release mechanism.