



## Crashbar Installation Instructions

### BBC Mount

---

Your crashbar kit includes a pair of adapter blocks designed to work with the BBC motor mount. Here's how to install them:

#### 1. Adapter Block Installation

- If the motor mount is already installed, begin by removing one of the **lower bolts** that secures the motor mount to the frame.
- Position one adapter block over the motor mount so that the **threaded holes** are oriented **above** the **counterbored holes**.
- Reinstall the bolt through one of the counterbored holes in the adapter block and into the frame.
- With the first bolt started, **remove the upper motor mount bolt**, rotate the adapter block into place, and reinstall the upper bolt through the second counterbored hole.
- **Torque both bolts** securely, completing one side at a time.

#### 2. Crashbar Installation

- With both adapter blocks in place, simply slide the crashbar into position.
- Attach the crashbar using the **supplied hardware**, threading the bolts into the **threaded holes** on the adapter blocks.

#### 3. Additional Step for 2006–2017 Dyna Models

- If you're installing on a **2006–2017 Dyna**, you'll need to **remove the regulator** from the frame before positioning the crashbar.
- Once the crashbar is mounted, **reinstall the regulator** onto the **relocation tab** provided on the crashbar.

---

**Thank you for choosing our product!**

If you have any questions or need support, feel free to reach out.