



Installation Instructions 2000-2017 Early Softail Forward Control Crashbar

Step 1: Attach the Lower Section of the Crashbar

Begin by attaching the **lower section of the crashbar** to the **factory crashbar mount** located at the bottom of the control mounts. Depending on your model, the forward control and floorboard controls may have slightly different mounting locations.

Step 2: Choose the Correct Mounting Holes

Our crashbar features **2 sets of holes** for mounting, but only one set will be used depending on the model of your bike.

- Select the appropriate set of holes for your specific model.
-

Step 3: Secure the Lower Mounting Points

For the lower mounting points, use the **3/8 allen bolts** with **nyloc nuts** to secure the crashbar to the selected hole locations.

Step 4: Attach the Upper Mount

The **upper mount** on the crashbar will align with the **factory upper crashbar mounting hole**.

- Install the **button head allen bolt** with the **nyloc nut** at this location to secure the crashbar.
-

Your crashbar is now installed and ready for use. Make sure all bolts are properly tightened before riding. Enjoy your ride!