

# **Fairing Bracket Kit Installation**

## **For 2013 & Earlier Road Glide**

1. The fairing brackets mount using the factory (OEM) hardware located at the **front of the gas tank** and at the **outer fairing edge**.
2. Remove the stock bolts at those two locations.
3. Position the bracket with its tabs pointing downward (towards the ground).
4. Reinstall the OEM bolts through the bracket and secure them in place.