



Installation Instructions

Sportster "SkyBar" and "Sky Scraper"

Forward Control Crashbar

Step 1: Remove Foot Control Mounts

- Begin by unbolting the **foot control mounts** from the frame. There are two **allen bolts** on each side securing the control mounts in place. Remove these bolts to detach the mounts.

Step 2: Remove Upper Motor Mount Bolts

- Next, remove the bolts securing the **upper motor mount** at the front of the bike to the frame.

Step 3: Install Crashbar

- Once the motor mount bolts are removed, position the **crashbar** in place.
- Start the **two factory bolts** through the **upper tab** on the crashbar and into the **motor mount location**. Leave these bolts loose for now to allow adjustment.

Step 4: Align Bottom of Crashbar with Frame

- Align the bottom of the crashbar with the **foot control mounting holes** in the frame.
- Install the **foot control mounts** over the bottom section of the crashbar, securing them with the **longer supplied bolts**.

Step 5: Torque All Bolts

- Once all bolts are started, tighten them to the proper torque specification.
- **Torque all bolts to 35 ft-lbs** to ensure a secure installation.