



Installation Instructions

2018 to Current Softail Kickstand Lift Block

Tools Required:

- 1/8" Drill Bit
- 17/64" Drill Bit
- Drill
- Wrenches/Socket Set
- Red Loctite
- Bolts (supplied)

Step 1: Remove the Kickstand

Begin by removing the kickstand from the frame. To do this, either:

- Remove the two mounting bolts that attach the kickstand mount to the frame, or
- Disconnect the return spring and remove the pivot pin.

Step 2: Position the Kickstand Lift Block

With the kickstand removed, place the **kickstand lift block** onto the base of the kickstand. Align the block so that the tip of the kickstand rests against the ledge of the block.

Step 3: Drill the Pilot Hole

Using a **1/8" drill bit**, drill through the kickstand using the pre-drilled **1/8" thru hole** in the lift block as your pilot hole.

Note: For some newer kickstand blocks, there may be multiple hole options. Choose the hole that aligns best with your kickstand to ensure proper clearance for the bolt. Only use this hole (or holes) for installation.

Step 4: Enlarge the Hole

Once the pilot hole is drilled, switch to a **17/64" drill bit** to enlarge the hole in the kickstand only. This will ensure that the bolt can pass through easily.

Step 5: Install the Kickstand Block

Position the **kickstand block** onto the kickstand and align the holes. Insert the supplied bolts through the block and kickstand. Apply **red Loctite** to the bolts before tightening to ensure a secure fit.

Step 6: Reinstall the Kickstand

After securing the kickstand block with the bolts, reinstall the kickstand back onto the bike by reversing the removal process. Tighten all mounting bolts to the manufacturer's specifications.